



Quick Start Guide

Bluetooth® Connectivity

20 hours of talk time

30 hours of standby time

Low battery indicator

Supports Hands Free Profile (HFP)



First Connection


1. Turn switch to "ON" position (two clicks, blinking green light).
2. Use the Phone Bluetooth interface to discover the MobileMic.
3. Connect to MobileMic, enter the pin "0000", wait for blue light. Some phones require you to initiate a connection again after pairing)

Connect MobileMic to Last Device

1. Turn off device if it is on.
2. Switch to "ON", wait for a green blink, then back to "Mute/Call Back"
3. Wait for the light green blinking to change to purple.
4. Switch back to "ON" before talking

Color Codes

Dark Green	=	Discoverable
Blue	=	Connected
Purple	=	Connected & Muted
Flashing Blue/Purple	=	Connected (Low Battery)
Flashing Green/Red	=	Discoverable (Low Battery)
Red w/Flashing Green	=	Muted Dialing Last Device



Note: By design the user will not hear themselves talking using the 3.5mm audio jack output at the base of the unit.